


**tomons**

## **User Guide**


DL1101 Smart Music Lighting



English

# English

## Overview



No.	Descriptions
A	Loudspeaker & the sensor bar
B	Volume- Button
C	Power Button (Press and hold to turn on/off). Press to pause.
D	Volume+ Button
E	MIC
F	Micro SD card slot
G	DC-5V MicroB charging port
H	Choosing play mode(normal mode or repeat one mode, only on Micro SD card mode)/ Battery percentage
I	Mode change (Bluetooth/Micro SD card/FM Mode)
J	Shutdown timer
K	Lanyard holes
L	Reset

## User Guide

- **Change brightness and color:** Press and hold ►|| to turn the lamp on. Touch the sensor bar on the top to change the brightness and color. You can choose six kinds of light including four kinds of white light with different brightness+ red light+gradient light.
- **Bluetooth speaker:** Press and hold ►||to turn the lamp on, and you will hear "Bluetooth ready, waiting for device connecting". Then, turn on the Bluetooth of your device and connect it to Tomons DL1101 to play music.
- **Play music in Micro-SD card:** Insert Micro-SD card in the lamp, then press and hold ►||to turn it on. To play music stored in Micro-SD card, press MODE button. Press ►|| to play or pause music. Press + for the next song and – for the previous song. To adjust volume, press and hold + or –. To repeat a single song, press Ⓢ shortly. Press Ⓢ again to play music in an orderly way.
- **FM Mode:** Press and hold ►|| to turn the lamp on. Press MODE button for FM mode. Press ►|| shortly to search FM, and you will see the indicator light flicker rapidly. Press + for the next FM or – for the previous one. Press and hold + or – to adjust the volume.
- **Shutdown timer:** Press Ⓢ to turn on shutdown timer. You can choose 10 min, 20 min, 30min, 60 min, 90 min or 120min. The device will be turned off accordingly. Press and hold Ⓢ to turn off shutdown timer.
- **Battery percentage:** Press and hold Ⓢ to know the battery percentage.
- **Answer the phone by Bluetooth:** You can answer phone by the device on condition that it has been connected to the Bluetooth in your phone. You can choose to answer or hang up the phone by touching the metal bar on the top or pressing ►||.

## Main Functions

1. RGB LED light with six kinds of light
2. Mono Bluetooth speaker
3. Answering the phone by Bluetooth
4. Playing the music stored in Micro SD card
5. FM Mode

## Technical Information

### Physical Characteristics

Dimensions	120mm*85mm*85mm (cylinder)
Weight	349g
Materials	ABS lamp base +PP lampshade+ stainless steel touch ring + ABS wire mesh board
Color	White

### Product Performance

Loudspeaker	1* $\varnothing$ 52 external magnetic field 4 $\Omega$ 4W    Max volume :80dB
Light	15*RGB LED light, 1.4W; touch adjust
Bluetooth edition	V2.1+EDR
Battery capacity	Internal Lithium Battery, 3.7V/2000MAh Normal volume+light, The device plays music for more than 8 consecutive hours; The Power Button blinks red as charging, and it stop blinking when the battery is fully charged.
Micro SD Card	Support up to 32G Micro-SD card and support MP3 and WAV files.
FM	Support FM 87.5-108.0Mhz

## Packing List

Smart music lighting	× 1
USB cable 80cm	× 1
Instruction Manual	× 1

## FAQs

1. I can't mix the light color myself.  
The light color has been set up when it was made, so you can't mix the light color yourself.
2. The Bluetooth can't be connected.
  - a. Ensure the device has been turned on and it is on Bluetooth Mode.
  - b. Ensure the distance between the device and your mobile phone is within 10 meters.
3. My SD card can't be read.
  - a. Ensure your SD card is no larger than 32 G.
  - b. Ensure songs stored in SD card are MP3 files or MAV files.
4. The FM function doesn't work well.  
Check if you are in places where the FM signals cannot be transmitted. If possible, go empty spaces without shielding to search FM.

## Warning

1. Don't expose the device to moisture because it is NOT waterproof.
2. Please charge the device within the rated voltage.
3. Avoid cleaning the device when charging it. You are supposed to separate the power supply from the device before you start cleaning.
4. Don't allow a child to play the device to prevent them from swallowing accessories.
5. Avoid listening to sound at high volumes since it may damage your hearing.

## Support

For any inquiries or comments concerning our products, please send an email to [support@lnateck.com](mailto:support@lnateck.com), and we will respond to you as soon as possible.

## Contact Information

### USA

Tel.: +1 513-644-9712

Phone hours: Weekdays 9 AM to 5 PM (EST)

Email: [support@inateck.com](mailto:support@inateck.com)

Web: [www.inateck.com](http://www.inateck.com)

Addr.: F&M Technology LLC, 9852 Crescent Park Drive,  
West Chester, OH 45069 USA

### Germany

Tel.: +49 342-07673081 Fax.: +49 342-07673082

Phone hours: Weekdays 9 AM-5 PM (CET)

Email: [support@inateck.com](mailto:support@inateck.com)

Web: <http://www.inateck.com/de/>

Addr.: F&M TECHNOLOGY GmbH, Montgolfierstraße 6,  
04509 Wiedemar

### Japan

Email: [support@inateck.com](mailto:support@inateck.com)

Web: [www.inateck.com/jp/](http://www.inateck.com/jp/)

Addr.: F&M株式会社 東京都昭島市拝島町三丁目10番3号

Made in China